SONIM XP7 IS

1. Loud Speaker
2. Volume
3. Sonim Protect® Alarm*
4. Recent Apps
5. Home
6. Back
7. Camera
8. PTT Button*
9. Power/Screen On/Off
10. Front Facing Camera
11. SIM Card Slot
12. Headset Port

*Check with service provider for availability

The XP7 IS is equipped with a glove touch screen. In order to be able to use the device while wearing gloves, please enable the glove mode on the device by going to Settings – Accessibility – Glove Mode.

Device comes equipped with pre-installed screen protector for added protection.

HOW TO INSERT THE SIM CARD

Step 1
Remove screw A using the screwdriver on the multi-tool. Remove headset port cover and screw completely.

Step 2
Remove screw B using the screwdriver on the multi-tool. Remove SIM cover and screw completely.

Step 3
Insert the pin on the multi-tool into the pinhole and press down. The SIM card tray will pop up. Use the pin to hook into the loop on top of the SIM card tray and remove the tray completely.

Step 4
Insert the SIM card in the tray and return the tray into the slot by pushing it in, making sure the pinhole is aligned next to the headset port.

Step 5
Secure both covers and screws in place using the screwdriver on the multi -tool.



Battery
The battery in your phone is not fully charged. We recommend that you charge the phone for five hours.

Warranty
Sonim Technologies provides a 3-Year comprehensive warranty.

Please register your phone within 30 days at www.sonimtech.com/register to receive product information and updates.

For more information related to warranty, contact your service provider.

Support
Contact us at:

Email: support_canada@sonimtech.com

Phone: 1-888-218-6999
Monday – Friday (24 hours a day)

Download the full user guide for your device: http://www.sonimtech.com

QUICK START GUIDE

SONIM XP7 IS

sonim
BUILT FOR LIFE™